

ADESSO WARRANTY

Adesso's warranty obligations are limited to the terms set forth below. Adesso warrants this hardware product against defects in materials and workmanship for a period of ONE (1) year from the date of original retail purchase.

If you discover a defect, Adesso will, at its option, repair or replace the product at no charge to you, provided you return it during the warranty period with transportation charges pre-paid to Adesso. You must contact Adesso for a Return Merchandise Authorization number (RMA) prior to returning any product. For each product returned for warranty service, please include your name, shipping address (no P.O. Box), telephone number, copy of the bill of sale as proof of purchase and have the package clearly marked with your RMA number.

For warranty service outside of the United States or Canada, customer must bear the cost of shipping in both directions. Please contact support@adesso.com for instructions.

THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS, WHETHER WRITTEN, ORAL, EXPRESS OR IMPLIED. ADESSO SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING AND WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. NO ADESSO DEALER, AGENT, OR EMPLOYEE IS AUTHORIZED TO MAKE ANY MODIFICATION, EXTENSION OR ADDITION TO THIS WARRANTY.

ADESSO IS NOT RESPONSIBLE FOR SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY, OR UNDER ANY LEGAL THEORY, INCLUDING BUT NOT LIMITED TO LOST

PROFITS, DOWNTIME, GOODWILL, DAMAGE TO OR REPLACEMENT OF EQUIPMENT OR PROPERTY AND ANY COST OF RECOVERING, REPROGRAMMING OR REPRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH ADESSO PRODUCTS. ADESSO'S MAXIMUM LIABILITY FOR ANY AND ALL DAMAGES ARISING OUT OF USE OF THE PRODUCT SHALL BE LIMITED TO THE AMOUNTS PAID BY PURCHASER FOR SUCH PRODUCT.

Some states do not allow the exclusion or limitation or limitation of incidental or consequential damages or exclusion of implied warranties, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

Adesso is a trademark of Adesso Inc. All other trademarks and trade names are property of their respective holders. Specifications and information in this publication are subject to change.

Please Note: Long-term repetitive use of any keyboard could cause injury to user. Adesso recommends users avoid excessive use of this or any keyboard.



Adesso Inc.

160 Commerce Way
Walnut, CA 91789
Phone (909) 839-2929
Fax (909) 839-2930
www.adesso.com

USER GUIDE



Tru-From Media



MODEL: PCK-208B

INTRODUCTION

This full-featured keyboard is designed to operate with your IBM or compatible computer system. The contoured ergonomic design helps increase productivity while the integrated touchpad saves time and valuable desk space.

FEATURES

- Ergonomic, contoured split-key design gently places your hands, wrists and arms in a more comfortable typing position.
- Extra-deep wrist support allows you to support your hands and wrists, when typing or at rest.
- 12 Function Keys, Num-Lock, Caps Lock and Scroll Lock LED indicators.

REQUIREMENTS

- Windows XP, 2000, Me, 98SE
- Available USB or PS/2 port

SETUP & INSTALLATION

For USB Installation:



- 1) Make sure that your computer is turned OFF before installing this keyboard or any other hardware device.

- 2) Locate the appropriate USB port on your computer.
- 3) Plug the USB connector into the rectangle USB port on your computer.
- 4) Turn on the computer.

For USB+PS/2 Adapter Installation:



- 1) Make sure that your computer is turned OFF before installing this keyboard or any other hardware device.
- 2) Connect the USB connector to the PS/2 converter.
- 3) Plug the PS/2 converter into the round PS/2 (purple) keyboard port on your computer. Turn on the computer.









SOFTWARE INSTALLATION

Please follow the instructions below to install the **Multimedia Keyboard** and Touchpad software onto your personal computer system.

1. Insert the CD included in your package labeled **Multimedia Keyboard** CD into your CD-ROM drive.
2. Open My Computer to explore the CD's contents.
3. The CD's contents are divided in 3 folders:

- Media Hot Keys (Software for Windows 2000, NT, 98SE)
- User Guide (Adobe® Acrobat® file)
- Run the installation software according to your current operating system.

HOT KEY FUNCTIONS

Function Name	Function Description
 Home	Launches the default Internet browser in your system.
 Favorites	Launches your favorite web page directory.
 E-Mail	Compose an e-mail using the default mail client.
 Volume +	Increases the volume of the current audio.
 Volume -	Decreases the volume of the current audio.
 Stop	Stops the audio/video file currently being played.
 Play/Pause	Plays/Pauses your video or audio media.
 Mute	Mute and Un-Mute the audio.

Congratulations on your purchase of an Adesso Tru-Form® Media Keyboard.

www.adesso.com